

# EXCAVATOR & QUICKHITCH REFERENCE GUIDE

	Page 1	Page 1	Page 2	Page 2	Page 3	Page 3	Page 4
MAKE	'Z'	'A'	B	B+	'C'	'D'	'E'
MODEL	Profile	Profile	Profile	Profile	Profile	Profile	Profile
AIRMAN	AX08	AX12/15	AX22/25	AX30	AX35	AX40/45	AX60/60.5
ATLAS		404		604			
BOBCAT	X316	X320	X325	X328	X331/334	X337/341	X442
CASE		CK13/15	CK25	CK28	CK36	CK50	CK62
CASE-NEW		C15	C23/28	C28/31	C35	C50	C70
CAT		301.5	302.5		303/4/5	304/305	307
DAEWOO		SO15		SO30	SO35	SO55	S70
HANIX	N080	H15	H26	N300	N350	450/50B	
HITACHI		EX15	EX22/25	EX30	EX35	EX40/45	EX60/60.5
HYUNDAI						55-5	
KOBELCO	SK07	SK15	SK025	SK30	SK35	SK45	SK60/70
KOBELCO	Imports		SK025	SK30	SK35	SK45	
JCB		801	802	802/803	2CX	805	3CX/JS70
KOMATSU	PC03	PC12/15	PC10/20	PC27	PC30	PC45	PC75/95
KUBOTA	K008	KX36/41	KX61	KX71	KX101	KX161	KX191
NISSAN		N150	N250	N300	N350		
PEL JOB		EB12	EB22/25	EB28/30		EB506	
SMC		MX15	MX30	MX30	MX35	MX50	
SUMITOMO						SH60	SH60
TAKEUCHI	TBO7	TBO15	TBO25		135	TBO45	TB175
VOLVO		EC14/15	EC250	EC250	EC35	EC45	EC70
YANMAR	B07	B15	B25/30	B25/30	B30/37	40/40V/50	VI070
Colours show pin size:			25/30mm	35/38mm	40mm	45mm	50mm

*Four easy steps to find the right bucket for your machine:*

1	Match the make and model and where it appears on the grid.			
2	Identify which profile relates to the profile.			
3	Go to the page relating to the profile. (if your machine appears in more than one grid you have a choice)			
4	Pickup the phone and dial PLANTFORCE: 01291 431111			